

## CARBON REFILL INSTRUCTIONS

1. Take the carbon filters out of the unit
2. Undo the 4 screws at top of the filter
3. Take the top cap plate off, along with the piece of foam and empty out the saturated carbon pellets into a garbage bag.
4. Fill the filter with the replacement carbon pellets
5. Tap the filter down to even the fill and fill to the top.
6. Flatten out the top layer of pellets
7. Install the piece of foam and the top cap plate – make sure the metal screen is inside the edges of the top plate – and replace the screws.
8. Reinstall the filters in the unit.

In case of difficulty, please contact ICA at 1 800 661 6211

